



User's manual

USB MIDI Pedal Controller

March 2015, Rev 1.0



For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se



The information in this document is subject to change without notice and does not represent a commitment on the part of TEControl. No part of this publication may be copied, reproduced or otherwise transmitted or recorded, for any purpose, without prior written permission by TEControl. All product and company names are [™] or ® trademarks of their respective owners.

© TEControl, 2015. All rights reserved.
Ragnarsv.2
23192 Trelleborg
Sweden

For general information about products: info@TEControl.se
For technical questions and enquiries: support@TEControl.se

For the most up to date information, visit the support pages at our web site <http://www.tecontrol.se> where you can find documentation and latest software.

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





1 TABLE OF CONTENT

Contents

1	Table of content	3
2	Revisions	3
3	Introduction.....	4
4	Overview.....	5
5	a word about pedals	6
5.1	Expression pedals.....	6
5.2	Sustain pedals	6
6	Getting started	7
6.1	Installation.....	7
6.2	Default settings	7
6.3	Configuration Utility.....	7
6.4	How to program	10
7	Control change numbers.....	12
8	Declaration of conformity	17

2 REVISIONS

Rev.	Date	Major changes
1.0	31-March-2015	First issue

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





3 INTRODUCTION

With the introduction of the USB MIDI Pedal Controller we are now able to provide users with the possibility to connect their existing expression and sustain pedals to the computer. The Pedal Controller offers the possibility to modify the sensitivity of the pedal and convert the signal to a MIDI CC (Control Change) of your choice and transmitting it to the computer as a MIDI class compliant USB device.

The TEControl team is very happy to be able to serve the MIDI community by providing innovative MIDI controllers. We intend to keep this business concurrent with both new developments and possibly provide back compatibility with older equipment.

All this said, we encourage suggestions for improvements and new products.

The TEControl team

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





4 OVERVIEW

The USB MIDI Pedal Controller is designed for musicians who want to connect standard expression and sustain pedals to their computers and add improved expression and realism to their performance and recordings.

The USB MIDI Pedal Controller offers enhanced controllability and flexibility by allowing sensitivity shaping and assignment to any MIDI channel and either CC, pitch bend, or aftertouch. While the aftertouch is straight forward, we have included three pitch bend modes: positive, negative and both, where the full function is available and can be tailored to usability with the sensitivity curve.

The USB MIDI Pedal Controller supports both expression and sustain pedals and is configurable for the two most common pedal wirings.

A monitor function simplifying the sensitivity adjustment is provided. This way players can optimize the sensitivity to their own style of playing. The attack and decay controls can be set from 0 to several seconds. This allows very smooth swells.

With the downloadable Configuration Utility all the parameters described above can be configured. Saving and loading presets is supported and very easy.

Signal processing algorithms guarantee full resolution over the configured sensor input range. The event-driven MIDI output streaming, filters out redundant data not to overflow your MIDI input and assures lowest latency. MIDI messages are transmitted only when input changes cause a change in the output value.

The USB MIDI Pedal Controller does not require installation of drivers or software. It will work with the default settings straight out of the box with both Windows and Mac OS. A Configuration Utility is available for both Mac and Windows and can be downloaded from our website and installed on your computer. The input is a 1/4" stereo (TRS) instrument jack and the output is through a USB MIDI class compliant device that connects directly to any computer USB port.

The USB MIDI Pedal Controller is intended to be used with existing expression and sustain pedals. No pedal is included.

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se




5 A WORD ABOUT PEDALS

5.1 Expression pedals

The most common expression pedals consist of a foot-operated potentiometer that has its three terminals connected to either a 1/4" stereo (TRS) instrument jack or an in-line cable plug.

There is no established standard for expression pedals and manufacturers use different ways to connect the potentiometer to the 1/4" stereo (TRS) instrument jack or in-line cable plug.


The two most common, connections are



CW — Sleeve
Wiper — Tip
CCW — Ring



and



CW — Sleeve
Wiper — Ring
CCW — Tip




Furthermore, the resistance of the potentiometer (i.e. between CW and CCW) is varying between manufacturers but most of them have a value between 10 - 50 kΩ.

It is normal for equipment using expression pedals as inputs to provide a supply voltage to the pedal and receive back a voltage proportional to the position of the wiper.

5.2 Sustain pedals

Sustain pedals are normally used for piano keyboards and are basically just an on/off switch or contact closure. They use a 1/4" mono (TRS) instrument jack or in-line cable plug.





6 GETTING STARTED

6.1 Installation

Connect your pedal to the USB MIDI Pedal Controller and the latter to a USB port on your computer (No software or driver installation is required). It will show as a **Pedal Controller** in your applications and is fully functional with the default settings (although depending on your pedal you might need to invert the jack polarity using the configuration utility, see below)

WARNING!!!

Only connect passive pedals to the USB MIDI Pedal Controller, i.e. pedals that are powered by mains supply, chargers or batteries must NOT be used. TEControl does not assume any responsibility for damage to any equipment (including the Pedal Controller itself) if these instructions are not followed.

6.2 Default settings

The **Pedal Controller** comes pre-configured with default settings and will work straight-out-of-the box. The default settings are as follows:

- *Bending and Symmetry – set to linear sensitivity*
- *Input and output ranges - set to maximum*
- *Attack and decay filters - disabled*
- *MIDI Channel - 1*
- *MIDI Message - Control change*
- *MIDI CC - 11 [expression]*
- *Jack Polarity - Tip=Wiper, Ring=Supply*

6.3 Configuration Utility

To change the default settings, download the latest version of the **Pedal Controller Configuration Utility** from the TEControl website, unzip it and run the installer. Settings can only be changed from a computer, not from a keyboard/synthesizer.

When started, the Configuration Utility will check for a connected **Pedal Controller**. If not found, the lower portion of the window will display an error message "Waiting for controller".






Figure 1 - Default settings

- 1 The left part of the window shows the current sensitivity curve stored in the controller and can be adjusted with the sliders in 2
- 2 All parameters can be adjusted with the sliders and drop down menus available here.
- 3 The **Configuration Utility** includes the possibilities to **Save** and **Load** as many presets as you like. This is very convenient since each sample library, VST instrument or keyboard/synthesizer might require different settings. The **Save preset** button lets you save the settings of both sensors to a file location and file name of your choice. The filename extension ".tpc" is added by default.
- 4 Located at the bottom of the window is a message window which reports the response of your actions as well as potential error messages.



In your DAW, player etc... the **Pedal Controller** must be selected as a MIDI input device in order to work. You must also configure the MIDI input of the track you are playing or recording to "MIDI omni", "All MIDI inputs" or similar function that configures the track to respond to all MIDI controllers. This is necessary to allow you to control the instrument from both keyboard and **Pedal Controller**.

WARNING!!!

Due to the nature of the MIDI standard, the parameter you control in your virtual instrument will in most cases retain the CC value it last received from the MIDI Controller.

You might get into a deadlock if e.g. you first use the Pedal Controller with CC 7 (volume), returning it to zero will leave your instrument volume at zero value, then change the CC to e.g. 11 (expression). No sound will be heard since the CC 7 (volume) is still at zero.

Please, keep this in mind before contacting support.

To solve the problem either restart your sample player or try the following:

- Select the CC that might be left at zero.
- While applying pedal pressure change the CC to e.g. 1 (mod wheel)
- Repeat if you have more CCs left at zero



6.4 How to program

The 8 sliders of the **Configuration Utility** let you tailor the response from input to output (MIDI CC, aftertouch or pitch bend value).

With the **Bending** and **Symmetry** sliders you can change the linear response to various shapes.

The **Input Min** sets the threshold of the input signal i.e. any signal below the threshold will not cause any change in the output CC value.

The **Input Max** can be used to set the level of pedal depression to apply in order to achieve max output value.

With the **Output Min** you can set the output CC value to be used for input signals below the input threshold. This is useful if you don't want the CC value to drop to zero.

The **Output Max** sets the maximum MIDI CC value to be sent.

The **Attack Filter** and **Decay Filter** sliders let you set the respective time constants individually. Setting the sliders fully left give you the fastest response and setting them fully right allows time constants of several seconds. This is very useful for semi-automatic swells.

The **Reset sensitivity** button resets the sensitivity to linear with full input and output ranges.

With the **MIDI Channel** drop-down list you set the MIDI channel to be used for the transmittal of the MIDI message.

The **MIDI CC** drop-down list lets you select the actual continuous controller to be used e.g. *CC1 [Modulation Wheel]*, *CC2 [Breath Control]* etc... See annex for a complete list. The **MIDI CC** is effective only when *Control Change* is selected in the **MIDI Message** drop-down list.

In the **MIDI Message** drop-down list you can in addition to the above mentioned *Control Change* also select *Aftertouch*, *Pitch Bend Up*, *Pitch Bend Down* and *Pitch Bend Both*. Note that when either *Aftertouch* or any of the *Pitch Bend* options are selected the **MIDI CC** drop down is grayed out.

Aftertouch is what the MIDI specification refers to as channel pressure.



Pitch Bend can be used in one direction (*Pitch Bend Up* or *Pitch Bend Down*) or in both directions (*Pitch Bend Both*) where the full function is available and can be tailored with the sensitivity curve.

Jack Polarity allows switching between the two different wiring configurations described in chapter 5. Selecting the wrong polarity will produce some signal but will not work as expected. However it will not damage either the pedal or the controller. If the pedal does not behave as expected, try the other polarity.

All the above changes to the settings take immediate effect but are lost when the computer is powered off or the **Pedal Controller** is removed from the computer. To store your settings permanently in the **Pedal Controller**, use the **Make permanent** button. This means your settings are remembered when the Breath controller is unpowered. You can now move it to another host with your favorite settings intact. Every time you use the **Make permanent** button the **Configuration Utility** stores the current parameters in the controller's non-volatile memory.

The **Configuration Utility** includes the possibilities to **Save** and **Load** as many presets as you like. This is very convenient since each sample library, VST instrument might require different settings.

The **Configuration Utility** includes an input monitor function where a dot is travelling along the sensitivity curve indicating the sensor input.



7 CONTROL CHANGE NUMBERS

The following table lists all currently defined **Control Change** messages and **Channel Mode** messages, in control number order. (Adopted from "MIDI by the Numbers" by D. Valenti-Electronic Musician 2/88, updated by the MIDI Manufacturers Association.)

Registered Parameter Numbers (RPNs) are an extension to the Control Change message for setting additional parameters. Appended at the bottom is a table of all currently defined RPNs.

Control Changes and Mode Changes (Status Bytes 176-191)					
Control Number (2nd Byte Value)			Control Function	3rd Byte Value	
Dec	Binary	Hex		Value	Used As
0	00000000	00	Bank Select	0-127	MSB
1	00000001	01	Modulation Wheel or Lever	0-127	MSB
2	00000010	02	Breath Controller	0-127	MSB
3	00000011	03	Undefined	0-127	MSB
4	00000100	04	Foot Controller	0-127	MSB
5	00000101	05	Portamento Time	0-127	MSB
6	00000110	06	Data Entry MSB	0-127	MSB
7	00000111	07	Channel Volume (formerly Main Volume)	0-127	MSB
8	00001000	08	Balance	0-127	MSB
9	00001001	09	Undefined	0-127	MSB
10	00001010	0A	Pan	0-127	MSB
11	00001011	0B	Expression Controller	0-127	MSB
12	00001100	0C	Effect Control 1	0-127	MSB
13	00001101	0D	Effect Control 2	0-127	MSB
14	00001110	0E	Undefined	0-127	MSB
15	00001111	0F	Undefined	0-127	MSB
16	00010000	10	General Purpose Controller 1	0-127	MSB
17	00010001	11	General Purpose Controller 2	0-127	MSB

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





18	00010010	12	General Purpose Controller 3	0-127	MSB
19	00010011	13	General Purpose Controller 4	0-127	MSB
20	00010100	14	Undefined	0-127	MSB
21	00010101	15	Undefined	0-127	MSB
22	00010110	16	Undefined	0-127	MSB
23	00010111	17	Undefined	0-127	MSB
24	00011000	18	Undefined	0-127	MSB
25	00011001	19	Undefined	0-127	MSB
26	00011010	1A	Undefined	0-127	MSB
27	00011011	1B	Undefined	0-127	MSB
28	00011100	1C	Undefined	0-127	MSB
29	00011101	1D	Undefined	0-127	MSB
30	00011110	1E	Undefined	0-127	MSB
31	00011111	1F	Undefined	0-127	MSB
32	00100000	20	LSB for Control 0 (Bank Select)	0-127	LSB
33	00100001	21	LSB for Control 1 (Modulation Wheel or Lever)	0-127	LSB
34	00100010	22	LSB for Control 2 (Breath Controller)	0-127	LSB
35	00100011	23	LSB for Control 3 (Undefined)	0-127	LSB
36	00100100	24	LSB for Control 4 (Foot Controller)	0-127	LSB
37	00100101	25	LSB for Control 5 (Portamento Time)	0-127	LSB
38	00100110	26	LSB for Control 6 (Data Entry)	0-127	LSB
39	00100111	27	LSB for Control 7 (Channel Volume, formerly Main Volume)	0-127	LSB
40	00101000	28	LSB for Control 8 (Balance)	0-127	LSB
41	00101001	29	LSB for Control 9 (Undefined)	0-127	LSB
42	00101010	2A	LSB for Control 10 (Pan)	0-127	LSB
43	00101011	2B	LSB for Control 11 (Expression Controller)	0-127	LSB
44	00101100	2C	LSB for Control 12 (Effect control 1)	0-127	LSB
45	00101101	2D	LSB for Control 13 (Effect control 2)	0-127	LSB
46	00101110	2E	LSB for Control 14 (Undefined)	0-127	LSB
47	00101111	2F	LSB for Control 15 (Undefined)	0-127	LSB
48	00110000	30	LSB for Control 16 (General Purpose Controller 1)	0-127	LSB
49	00110001	31	LSB for Control 17 (General Purpose Controller 2)	0-127	LSB
50	00110010	32	LSB for Control 18 (General Purpose Controller 3)	0-127	LSB
51	00110011	33	LSB for Control 19 (General Purpose Controller 4)	0-127	LSB

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





52	00110100	34	LSB for Control 20 (Undefined)	0-127	LSB
53	00110101	35	LSB for Control 21 (Undefined)	0-127	LSB
54	00110110	36	LSB for Control 22 (Undefined)	0-127	LSB
55	00110111	37	LSB for Control 23 (Undefined)	0-127	LSB
56	00111000	38	LSB for Control 24 (Undefined)	0-127	LSB
57	00111001	39	LSB for Control 25 (Undefined)	0-127	LSB
58	00111010	3A	LSB for Control 26 (Undefined)	0-127	LSB
59	00111011	3B	LSB for Control 27 (Undefined)	0-127	LSB
60	00111100	3C	LSB for Control 28 (Undefined)	0-127	LSB
61	00111101	3D	LSB for Control 29 (Undefined)	0-127	LSB
62	00111110	3E	LSB for Control 30 (Undefined)	0-127	LSB
63	00111111	3F	LSB for Control 31 (Undefined)	0-127	LSB
64	01000000	40	Damper Pedal on/off (Sustain)	≤63 off, ≥64 on	---
65	01000001	41	Portamento On/Off	≤63 off, ≥64 on	---
66	01000010	42	Sostenuto On/Off	≤63 off, ≥64 on	---
67	01000011	43	Soft Pedal On/Off	≤63 off, ≥64 on	---
68	01000100	44	Legato Footswitch	≤63 Normal, ≥64 Legato	---
69	01000101	45	Hold 2	≤63 off, ≥64 on	---
70	01000110	46	Sound Controller 1 (default: Sound Variation)	0-127	LSB
71	01000111	47	Sound Controller 2 (default: Timbre/Harmonic Intens.)	0-127	LSB
72	01001000	48	Sound Controller 3 (default: Release Time)	0-127	LSB
73	01001001	49	Sound Controller 4 (default: Attack Time)	0-127	LSB
74	01001010	4A	Sound Controller 5 (default: Brightness)	0-127	LSB
75	01001011	4B	Sound Controller 6 (default: Decay Time - see MMA RP-021)	0-127	LSB
76	01001100	4C	Sound Controller 7 (default: Vibrato Rate - see MMA RP-021)	0-127	LSB
77	01001101	4D	Sound Controller 8 (default: Vibrato Depth - see MMA RP-021)	0-127	LSB
78	01001110	4E	Sound Controller 9 (default: Vibrato Delay - see MMA RP-021)	0-127	LSB
79	01001111	4F	Sound Controller 10 (default undefined - see MMA RP-021)	0-127	LSB

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





80	01010000	50	General Purpose Controller 5	0-127	LSB
81	01010001	51	General Purpose Controller 6	0-127	LSB
82	01010010	52	General Purpose Controller 7	0-127	LSB
83	01010011	53	General Purpose Controller 8	0-127	LSB
84	01010100	54	Portamento Control	0-127	LSB
85	01010101	55	Undefined	---	---
86	01010110	56	Undefined	---	---
87	01010111	57	Undefined	---	---
88	01011000	58	High Resolution Velocity Prefix	0-127	LSB
89	01011001	59	Undefined	---	---
90	01011010	5A	Undefined	---	---
91	01011011	5B	Effects 1 Depth (default: Reverb Send Level - see MMA RP-023) (formerly External Effects Depth)	0-127	---
92	01011100	5C	Effects 2 Depth (formerly Tremolo Depth)	0-127	---
93	01011101	5D	Effects 3 Depth (default: Chorus Send Level - see MMA RP-023) (formerly Chorus Depth)	0-127	---
94	01011110	5E	Effects 4 Depth (formerly Celeste [Detune] Depth)	0-127	---
95	01011111	5F	Effects 5 Depth (formerly Phaser Depth)	0-127	---
96	01100000	60	Data Increment (Data Entry +1) (see MMA RP-018)	N/A	---
97	01100001	61	Data Decrement (Data Entry -1) (see MMA RP-018)	N/A	---
98	01100010	62	Non-Registered Parameter Number (NRPN) - LSB	0-127	LSB
99	01100011	63	Non-Registered Parameter Number (NRPN) - MSB	0-127	MSB
100	01100100	64	Registered Parameter Number (RPN) - LSB*	0-127	LSB
101	01100101	65	Registered Parameter Number (RPN) - MSB*	0-127	MSB
102	01100110	66	Undefined	---	---
103	01100111	67	Undefined	---	---
104	01101000	68	Undefined	---	---
105	01101001	69	Undefined	---	---
106	01101010	6A	Undefined	---	---
107	01101011	6B	Undefined	---	---
108	01101100	6C	Undefined	---	---
109	01101101	6D	Undefined	---	---
110	01101110	6E	Undefined	---	---
111	01101111	6F	Undefined	---	---

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se





112	01110000	70	Undefined	---	---
113	01110001	71	Undefined	---	---
114	01110010	72	Undefined	---	---
115	01110011	73	Undefined	---	---
116	01110100	74	Undefined	---	---
117	01110101	75	Undefined	---	---
118	01110110	76	Undefined	---	---
119	01110111	77	Undefined	---	---
Note: Controller numbers 120-127 are reserved for Channel Mode Messages, which rather than controlling sound parameters, affect the channel's operating mode. (See also Table 1.)					
120	01111000	78	[Channel Mode Message] All Sound Off	0	---
121	01111001	79	[Channel Mode Message] Reset All Controllers (See MMA RP-015)	0	---
122	01111010	7A	[Channel Mode Message] Local Control On/Off	0 off, 127 on	---
123	01111011	7B	[Channel Mode Message] All Notes Off	0	---
124	01111100	7C	[Channel Mode Message] Omni Mode Off (+ all notes off)	0	---
125	01111101	7D	[Channel Mode Message] Omni Mode On (+ all notes off)	0	---
126	01111110	7E	[Channel Mode Message] Mono Mode On (+ poly off, + all notes off)	Note: This equals the number of channels, or zero if the number of channels equals the number of voices in the receiver.	---
127	01111111	7F	[Channel Mode Message] Poly Mode On (+ mono off, +all notes off)	0	---

For more information on any of our products or services please visit us on the Web at:

www.TEControl.se





8 DECLARATION OF CONFORMITY

Declaration of Conformity

Supplier's Name: **TEControl**

Supplier's Address: **Ragnarsv. 2, 23192 Trelleborg, Sweden**

Supplier's email: info@tecontrol.se

declares that the product **USB Midi Pedal Controller** conforms to the following

EMC:

EN 55022:2010

EN 55024:2010

RoHS:

EN 50581:2012

The product herewith complies with the requirements of the RoHS Directive 2011/65/EU, the EMC Directive 2004/108/EC and carries the CE marking accordingly.

The product herewith is exempt from the specific technical standards and other requirements contained in Part 15 of the FCC rules, according to FCC 15.103(g).

Trelleborg, 31.03.2015



Owner, TEControl

For more information on
any of our products or
services please visit us
on the Web at:

www.TEControl.se

